Customizing Your Lexus

Your vehicle includes a variety of electronic features that can be personalized to your preferences. Programming these preferences requires specialized equipment and can be performed by an authorized Lexus dealership.

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

<table>
<tr><th>Item</th><th>Function</th><th>Default setting</th><th>Customized setting</th></tr>
<tr><td rowspan="2">Smart access system with push-button start</td><td>Operation signal (Emergency flashers)</td><td>On</td><td>Off</td></tr>
<tr><td>Operation signal (Buzzer)</td><td>On</td><td>Off</td></tr>
<tr><td rowspan="11">Wireless remote control</td><td>Unlocking operation</td><td>Driver's door unlocked in one step, all doors unlocked in two steps</td><td>All doors unlocked in one step</td></tr>
<tr><td>Automatic door lock function to be activated if door is not opened after being unlocked</td><td>On</td><td>Off</td></tr>
<tr><td rowspan="2">Time elapsed before automatic door lock function is activated if door is not opened after being unlocked</td><td rowspan="2">60 seconds</td><td>30 seconds</td></tr>
<tr><td>120 seconds</td></tr>
<tr><td>Operation signal (Emergency flashers)</td><td>On</td><td>Off</td></tr>
<tr><td>Operation signal (Buzzer)</td><td>On</td><td>Off</td></tr>
<tr><td>Door lock buzzer</td><td>On</td><td>Off</td></tr>
<tr><td>Trunk unlocking function</td><td>On</td><td>Off</td></tr>
<tr><td rowspan="2">Trunk unlocking operation</td><td rowspan="2">Push and hold</td><td>Push twice</td></tr>
<tr><td>One short push</td></tr>
<tr><td>Panic function</td><td>On</td><td>Off</td></tr>
</table>

Customizing Your Lexus

Item	Function	Default setting	Customized setting
Door lock	Unlocking using a key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step
	Speed-detecting automatic door lock function	Off	On
	Opening driver's door unlocks all doors	Off	On
	Shifting gears to P unlocks all doors	On	Off
	Shifting gears to a position other than P locks all doors	On	Off
Steering wheel	Auto tilt-away function	On	Off
Power windows	Linked door lock operation	On	Off
	Linked door key operation	Open and close	Open only Close only
	Wireless remote control linked operation	Off	Open only
Moon roof	Linked door lock operation	On	Off
	Linked door key operation	Open and close	Open only Close only
	Linked operation of components when door key is used	Slide only	Tilt only
	Wireless remote control linked operation	Off	Open only
	Linked operation of components when wireless remote control is used	Off	Slide only Tilt only
Automatic light control system	Light sensor sensitivity	Level 3	Level 1 to 5
	Time elapsed before headlights automatically turn off after doors are closed	30 seconds	0 seconds 60 seconds 90 seconds
Lights	Daytime running light system (U.S.A. only)	On	Off

Item	Function	Default setting	Customized setting
Windshield wipers and washer	Switching operation when the vehicle is stationary	On	Off
	Drip prevention function	On	Off
	Time elapsed before the drip prevention function operates	Variable depending on the vehicle speed	3 seconds
Intuitive parking assist	Back sensor operation display and buzzer	On	Off
	Buzzer volume	Level 3	Level 1 to 5
	Distance which a sensor detects	4.9 ft. (150 cm)	2.0 ft. (60 cm)
Illumination	Time elapsed before lights turn off	15 seconds	7.5 seconds
			30 seconds
	Operation when the doors are unlocked	On	Off
	Operation after the “ENGINE START STOP” switch is turned OFF	On	Off
	Front footwell lights	On	Off
	Shift lever light	On	Off
	Outer foot lights	On	Off
Seat belt reminder	Vehicle speed linked seat belt reminder buzzer	On	Off

Your Lexus dealer

Your Lexus dealer will provide quality maintenance and any other assistance you may require.

If there is not a Lexus dealer near you, please call the following number:

■ U.S. OWNERS

● In the U.S. mainland or Canada:
Lexus Roadside Assistance
1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)

● In Hawaii:
Servco Automotive Roadside Assistance/Customer Services
1-800-25-LEXUS or 1-800-255-3987 (Toll-Free)

■ CANADIAN OWNERS

● In Canada or the U.S. mainland:
Lexus Roadside Assistance/Customer Service
1-800-26-LEXUS or 1-800-265-3987 (Toll-Free)

Please access our **websites** for further information.

● The U.S. mainland: www.lexus.com
● Hawaii: www.servcolexus.com
● Canada: www.lexus.ca